



AIR SWITCH | code ASC

Installation Instructions

Ikon Commercial Limited HAMILTON Ph: 0800 83 83 84 Fx: 0800 83 83 85 info@ikoncommercial.co.nz

READ THIS INSTURCTION MANUAL CAREFULLY BEFORE INSTALLING AND USING THIS PRODUCT.

PLEASE KEEP THESE INSTRUCTIONS HANDY FOR FUTURE REFERENCE

IMPORTANT

Always operate the product from a power source of the same voltage, frequency and rating as what is indicated on the product identification label. You can find this label on the bottom of the air switch.

Do NOT operate this product if the power cord is damaged, or the product appears damaged in any manner.

Do NOT immerse or expose any part of this product in any liquid, or expose the electrical part to any moisture, or located the electrical part near basins or other vessels containing water or other liquid.

INSTALLATION AND USAGE

This product contains four components, including:

- Button (in silver chrome finish)
- Spare button cover in alternative finish (white)
- Air tube
- Air switch including cord and three-pin plug

To change the colour of the bellows button and surround, grasp the body of the bellows and pull the surround (outer ring) from the bellows body. The button assembly can then be removed from the bellows body, remove and replace with the preferred colour and reassemble into the bellows body.

To install the button, drill a 33mm hole into the work surface or sink, at the preferred position of the working bench. Remove the back nut and the washer first, then fit the button through the hole. Fits the large washer back on, then the back nut, hand tighten only.

Mount the air switch adjacent to the product to be controlled in a dry location vertically. Then connect the air switch and the button with the air tube provided.

Plug the air switch into an AC power point (ensuring the power point is grounded properly). This power point should be of the same voltage, frequency and Rating with that on the product identification label. **Make sure the AC power point is switched off.**

Plug the product to be controlled into the air switch 3-pin socket. Turn on the AC power point. Press the button to control (turn on / off) the product.

This product is under I year return to base warranty